




KÄRCHER

OPERATOR'S MANUAL



<u>MODEL #</u>	<u>ORDER #</u>	<u>MODEL #</u>
HD 2.3/24 P	1.575-100.0	DG-232437
HD 2.5/27 P	1.575-101.0	DG-252737
HD 3.0/30 P	1.575-102.0	DG-303037
HD 3.5/32 P	1.575-103.0	DG-353237
HD 3.8/35 P	1.575-104.0	DG-383537
HD 2.3/23 P	1.575-110.0	DG-232336

To locate your local Kärcher Commercial Pressure Washer Dealer nearest you,
please visit www.karchercommercial.us

9.800-082.0

CONTENTS

Important Safety Information	4-5
Component Identification	6
Assembly Instructions.....	7
Operating Instructions.....	8-9
Applying Detergent and General Operating Techniques.....	10
Shut Down and Clean-Up	11
Storage	11
Troubleshooting	12-13
Preventative Maintenance	14
Oil Change Record	14
Exploded View	15
Exploded View Parts List	16-17
Specifications.....	18
VBA35 Unloader Exploded View and Parts List	19
KG Pump Exploded View and Parts List.....	20-21
KS-1 Pump Exploded View and Parts List.....	22-23
Warranty	

Model Number _____

Serial Number _____

Date of Purchase _____

The model and serial numbers will be found on a decal attached to the pressure washer. You should record both serial number and date of purchase and keep in a safe place for future reference.

INTRODUCTION & IMPORTANT SAFETY INFORMATION

Thank you for purchasing this Pressure Washer. We reserve the right to make changes at any time without incurring any obligation.

Owner/User Responsibility:

The owner and/or user must have an understanding of the manufacturer's operating instructions and warnings before using this pressure washer. Warning information should be emphasized and understood. If the operator is not fluent in English, the manufacturer's instructions and warnings shall be read to and discussed with the operator in the operator's native language by the purchaser/owner, making sure that the operator comprehends its contents.

Owner and/or user must study and maintain for future reference the manufacturers' instructions.

The operator must know how to stop the machine quickly and understand the operation of all controls. Never permit anyone to operate the engine without proper instructions.


This manual should be considered a permanent part of the machine and should remain with it if machine is resold.

When ordering parts, please specify model and serial number.

This machine is to be used only by trained operators.

IMPORTANT SAFETY INFORMATION

WARNING: When using this machine basic precautions should always be followed, including the following:



CAUTION: To reduce the risk of injury, read operating instructions carefully before using.

1. Failure to follow instructions could cause malfunction of the machine and result in death, serious bodily injury and/or property damage.
2. Know how to stop the machine and bleed pressure quickly. Be thoroughly familiar with the controls.
3. Stay alert — watch what you are doing.
4. All installations must comply with local codes. Contact your electrician, plumber, utility company or the selling distributor for specific details.



WARNING: Risk of asphyxiation. Use this product only in a well ventilated area.

5. Avoid installing machines in small areas or near exhaust fans. Exhaust contains poisonous carbon monoxide gas; exposure may cause loss of consciousness and may lead to death. It also contains

chemicals known, in certain quantities, to cause cancer, birth defects or other reproductive harm.



WARNING: Flammable liquids can create fumes which can ignite causing property damage or severe injury.

WARNING: Risk of fire. Do not add fuel when the product is operating.

WARNING: Risk of explosion — do not spray flammable liquids.

6. Do not place machine near flammable objects as the engine is hot.
7. Allow engine to cool for 1-2 minutes before refueling. If any fuel is spilled, make sure the area is dry before testing the spark plug or starting the engine. (Fire and/or explosion may occur if this is not done.)

Gasoline engines on mobile or portable equipment shall be refueled:

- a. outdoors;
- b. with the engine on the equipment stopped;
- c. with no source of ignition within 10 feet of the dispensing point; and
- d. with an allowance made for expansion of the fuel should the equipment be exposed to a higher ambient temperature.

In an overfilling situation, additional precautions are necessary to ensure that the situation is handled in a safe manner.

8. Transport/repair with fuel tank EMPTY or with fuel shut-off valve OFF.



WARNING: Keep wand, hose, and water spray away from electric wiring or fatal electric shock may result.

INTRODUCTION & IMPORTANT SAFETY INFORMATION

WARNING



WARNING: Flammable liquids can create fumes which can ignite, causing property damage or severe injury.

WARNING: Risk of explosion — Do not spray flammable liquids.

9. Do not allow acids, caustic or abrasive fluids to pass through the pump.
10. Keep operating area clear of all persons.


WARNING



WARNING: High pressure spray can cause paint chips or other particles to become airborne and fly at high speeds. To avoid personal injury, eye, hand and foot safety devices must be worn.


11. Eye, hand, and foot protection must be worn when using this equipment.

WARNING



WARNING: Grip cleaning wand securely with both hands before starting. Failure to do this could result in injury from a whipping wand.

WARNING



WARNING: High pressure developed by these machines will cause personal injury or equipment damage. Keep clear of nozzle. Use caution when operating. Do not direct discharge stream at people, or severe injury or death will result.

12. To reduce the risk of injury, close supervision is necessary when a machine is used near children. Do not allow children to operate the pressure washer. **This machine must be attended during operation.**

WARNING



WARNING: Be extremely careful when using a ladder, scaffolding or any other relatively unstable location. The cleaning area should have adequate slopes and drainage to reduce the possibility of a fall due to slippery surfaces.

13. Do not overreach or stand on unstable support. Keep good footing and balance at all times.
14. Follow the maintenance instructions specified in the manual.

WARNING




WARNING: Protect machine from freezing.

15. To keep machine in best operating conditions, it is important you protect machine from freezing. Failure to protect machine from freezing could cause malfunction of the machine and result in death, serious bodily injury, and/or property damage. Follow storage instructions specified in this manual.
16. Inlet water must be clean fresh water and no hotter than 90°F.
17. Never make adjustments on machine while in operation.
18. Be certain all quick coupler fittings are secured before using pressure washer.
19. Manufacturer will not be liable for any changes made to our standard machines, or any components not purchased from us.
20. The best insurance against an accident is precaution and knowledge of the machine.
21. Do not operate this machine when fatigued or under the influence of alcohol, prescription medications, or drugs.

PRE-OPERATION CHECK

- Check pump oil level. (Use SAE 30W non-detergent oil). Dipstick is located on top of pump.
- Cold water supply (minimum 6 gpm, 5/8", 20 psi)
- Hose, wand, nozzles (nozzle sizes per serial plate)
- Water filter (intact, non restrictive)
- Fuel (unleaded 86 or higher octane)
- Open spray gun to relieve pressure before starting.
- Engine oil (SAE 10W30)

COMPONENT IDENTIFICATION



Pump — Develops high pressure.

Starter Grip — Used for starting the engine manually.

Spray Gun — Controls the application of water and detergent onto cleaning surface with trigger device. Includes safety latch.

Detergent Injector — Allows you to siphon and mix detergents.


Wand — Must be connected to the spray gun.

High Pressure Hose — Connect one end to water pump discharge nipple and the other end to spray gun.


Pump Protector — Cycles fresh cool water through pump when recirculating water reaches 140°F.

Note: If trigger on spray gun is released for more than 1-2 minutes, water will leak from valve. Warm water will discharge from pump protector onto floor. This system prevents internal pump damage.


ASSEMBLY INSTRUCTIONS




STEP 1: Attach the handle to the frame of the pressure washer.
Note: It may be necessary to move the handle supports from side to side in order to align the handle so it will slide over the frame supports.




STEP 2: Insert the carriage bolt through the holes from the outside of the unit and attach a nut from the inside of the machine. Tighten nuts.




STEP 3: Attach the spray gun/hose storage handle and bracket to handle. Tighten nuts.




STEP 4: Attach the high pressure hose to the spray gun using teflon tape on hose threads.




STEP 5: Attach nozzle extension to spray gun/wand. Tighten both by hand.




STEP 6: Pull the spring-loaded collar of the wand coupler back to insert your choice of pressure nozzle.




STEP 7: Release the coupler collar and push the nozzle until the collar clicks. Pull the nozzle to make sure it is seated properly.



STEP 8: Connect the high pressure hose to the pump discharge nipple. Push coupler collar forward until secure.




STEP 9: Connect (7.5m) garden hose to the cold water source.




STEP 10: Check inlets filters, remove debris, then connect the garden hose to pump water inlet.
CAUTION: Do not run the pump without water or pump damage will result.


OPERATING INSTRUCTIONS




STEP 1: Check engine oil level. Oil level should be level with the bottom of the oil filler neck. Be sure the machine is level when checking the oil level. (Refer to the engine's operating manual included with machine.) We recommend that the oil be changed after the first 5 hours of use, then once every 50 hours. **Note:** Improper oil levels will cause low oil sensor to shut off engine. **IMPORTANT! Do not run engine with high or low oil levels as this will cause engine damage.**




STEP 2: Remove shipping cap and install oil dipstick. Check pump oil level by using dipstick or observe oil level in oil window (if equipped). **Use 30 wt. (non detergent) oil.**




STEP 3: Fill gas tank with unleaded gasoline. Do not use leaded gasoline.



STEP 4: Trigger the spray gun to eliminate trapped air then wait for a steady flow of water to emerge from the spray nozzle.




STEP 5: Rotate the fuel shut-off valve to the "On" position. Slide the fuel valve lever to the "ON" position. When the engine is not in use, leave the fuel valve in the "OFF" position.




STEP 6: Move the choke lever to the "Choke" position (on a warm engine, leave the choke lever in the run position). Move the choke lever to the "Closed" position. To restart a warm engine, leave the choke lever in the "Open" position.

OPERATING INSTRUCTIONS (CON'T)




STEP 8: Turn the engine switch to "On" position.

On Briggs engines, move the throttle lever to "Fast" position, shown on the engine as a rabbit.




STEP 9: Pull the starter grip. If the engine fails to start after 2 pulls, squeeze the trigger gun to release pressure and repeat step. Return starter gently. After the engine warms up enough to run smoothly, move choke to run position and throttle to fast position.

CAUTION: Small engines may kick back. Do not hold pull starter grip tightly in hand.



⚠ WARNING! Never replace nozzles without engaging the safety latch on the spray gun trigger.



The five color-coded quick connect nozzles provide a wide array of spray widths from 0° to 45° and are easily accessible when placed in the convenient rubber nozzle holder, which is provided on the front of the machine.

NOTE: For a more gentle rinse, select the white 40° or green 25° nozzle. To scour the surface, select the yellow 15° or red 0° nozzle. To apply detergent select the black nozzle.

DETERGENT AND GENERAL CLEANING TECHNIQUES



WARNING




WARNING: Some detergents may be harmful if inhaled or ingested, causing severe nausea, fainting or poisoning. The harmful elements may cause property damage or severe injury.

STEP 1: Connect detergent injector to discharge nipple on machine.

Connect high pressure hose to injector with quick coupler. (Check to make sure locking coupler sleeves are in proper position before applying water pressure).



STEP 2: Use detergent designed specifically for pressure washers. Prepare detergent solution as required by the manufacturer. Fill a container with pressure washer detergent. Place the filter end of detergent suction tube into the detergent container.



STEP 3: With safety latch on spray gun engaged, secure black detergent nozzle into quick coupler. **NOTE:** Detergent cannot be applied using red, yellow, green or white nozzles.

STEP 4: With the engine running, pull trigger to operate machine. Liquid detergent is drawn into the machine and mixed with water. Apply detergent to work area. Do not allow detergent to dry on surface.

IMPORTANT: You must flush the detergent injection system after each use by placing the suction tube into a bucket of clean water, then run the pressure washer in low pressure for 1-2 minutes.

THERMAL PUMP PROTECTION

If you run the engine on your pressure washer for 1-2 minutes without pressing the trigger on the spray gun, circulating water in the pump can reach high temperatures. When the water reaches this temperature, the pump protector engages and cools the pump by discharging the warm water onto the ground. This thermal device prevents internal damage to the pump.

CLEANING TIPS

Pre-rinse cleaning surface with fresh water. Place detergent suction tube directly into cleaning solution and apply to surface at low pressure (for best results, limit your work area to sections approximately 6 feet square and always apply detergent from bottom to top). Allow detergent to remain on surface 1-3 minutes. Do not allow detergent to dry on surface. If surface appears to be drying, simply wet down surface with fresh water. If needed, use brush to remove stubborn dirt. Rinse at high pressure from top to bottom in an even sweeping motion keeping the spray nozzle approximately 1 foot from cleaning surface. Use overlapping strokes as you clean and rinse any surface. For best surface cleaning action spray at a slight angle.

Recommendations:

- Before cleaning any surface, an inconspicuous area should be cleaned to test spray pattern and distance for maximum cleaning results.
- If painted surfaces are peeling or chipping, use extreme caution as pressure washer may remove the loose paint from the surface.
- Keep the spray nozzle a safe distance from the surface you plan to clean. High pressure wash a small area, then check the surface for damage. If no damage is found, continue to pressure washing.

CAUTION - Never use:


- Bleach, chlorine products and other corrosive chemicals
- Liquids containing solvents (i.e., paint thinner, gasoline, oils)
- Tri-sodium phosphate products
- Ammonia products
- Acid-based products

These chemicals will harm the machine and will damage the surface being cleaned.


RINSING

It will take a few seconds for the detergent to clear. Apply safety latch to spray gun. Remove black soap nozzle from the quick coupler. Select and install the desired high pressure nozzle. **NOTE:** You can also stop detergent from flowing by simply removing detergent siphon tube from bottle.


SHUTTING DOWN AND CLEAN-UP




STEP 1: Remove detergent suction tube from container and insert into one gallon of fresh water. Slide nozzle forward for low pressure or to connect black detergent nozzle. Pull trigger on spray gun and siphon water for one minute.




STEP 2: Turn off the engine.




STEP 3: Turn off water supply.




STEP 4: Press trigger to release water pressure.



STEP 5: Disconnect the garden hose from the water inlet on the machine.



STEP 6: Disconnect the high pressure hose from pump discharge nipple.



STEP 7: Engage the spray gun safety lock.

STORAGE

CAUTION: Always store your pressure washer in a location where the temperature will not fall below 32°F (0°C). The pump in this machine is susceptible to permanent damage if frozen. **FREEZE DAMAGE IS NOT COVERED BY WARRANTY.**

1. Stop the pressure washer, squeeze spray gun trigger to release pressure.
2. Detach water supply hose and high pressure hose.
3. Turn on the machine for a few seconds, until remaining water exits. Turn engine off immediately.
4. Drain the gas from the engine.
5. Do not allow high pressure hose to become kinked.
6. Store the machine and accessories in a room which does not reach freezing temperatures.

CAUTION: Failure to follow the above directions will result in damage to your pressure washer.

When the pressure washer is not being operated or is being stored for more than one month, follow these instructions:

1. Replenish engine oil to upper level.
2. Drain gasoline from fuel tank, fuel line, fuel valve and carburetor.
3. Pour about one teaspoon of engine oil through the spark plug hole, pull the starter grip several

times and replace the plug. Then pull the starter grip slowly until you feel increased pressure which indicates the piston is on its compression stroke and leave it in that position. This closes both the intake and exhaust valves to prevent rusting of cylinder.

4. Cover the pressure washer and store in a clean, dry place that is well ventilated away from open flame or sparks. **NOTE:** The use of a fuel additive, such as STA-BIL®, or an equivalent, will minimize the formulation of fuel deposits during shortage. Such additives may be added to the gasoline in the fuel tank of the engine, or to the gasoline in a storage container.

After Extended Storage

CAUTION: Prior to restarting, thaw out any possible ice from pressure washer hoses, spray gun or wand.



Engine Maintenance

During the winter months, rare atmospheric conditions may develop which will cause an icing condition in the carburetor. If this develops, the engine may run rough, lose power and may stall. This temporary condition can be overcome by deflecting some of the hot air from the engine over the carburetor area.

NOTE: Refer to the engine manufacturer's manual for service and maintenance of the engine.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
LOW OPERATING PRESSURE	Insufficient water supply. Closed faucet. Inlet hose kinked	Use larger garden hose; clean inlet water screen. Open faucet.
	Clogged inlet hose strainer	Check plumbing system for leaks. Re-tape leaks with Teflon tape.
	Faulty or improperly adjusted unloader valve	Adjust unloader for proper pressure. Install repair kit when needed. Contact local dealer.
	Worn packing in pump	Contact local dealer.
	Machine has been stored in freezing temperatures	Thaw out machine completely, including hose, spray gun and wand.
	Slow engine RPM	Contact local dealer.
FLUCTUATING PRESSURE	Worn or dirty pump valves	Contact local dealer.
	Nozzle is obstructed	Blow out or remove debris with fine needle.
	Pump sucking air, inlet hose leaking	Check all pump lines and connections.
PRESSURE LOW AFTER PERIOD OF NORMAL USE	Nozzle worn	Replace nozzle.
	Unloader valve worn	Replace unloader valve.
ENGINE WILL NOT START OR STOPS WHILE OPERATING	Low oil shutdown	Fill engine with oil.
	Out of gas	Fill fuel tank.
	Water in gasoline	Drain gas tank; fill with clean fuel.
ENGINE IS OVERLOADED	Nozzle partially blocked	Clean nozzle.
	Excessive pressure from high engine RPM	Adjust engine throttle to lower RPM.
WATER OR OIL LEAKING FROM BOTTOM OF PUMP	A small amount of leaking is normal	If excessive leaking occurs, Contact local dealer.
PRESENCE OF WATER IN PUMP OIL	Water sprayed at machine	Change oil. Direct spray away from machine.
	High humidity in air	Check and change oil twice as often.
	Piston packing worn. Oil seal worn.	Contact local dealer.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
ENGINE OPERATES FOR 15 MIN. THEN STOPS	Not enough gas or engine oil	Fill tank with gas. Check oil level.
	Vapor lock developed by heat of day	Keep gas tank full to avoid vapor locking.
	Obstruction in fuel filter	Clean or replace fuel filter.
ENGINE LACKS POWER	Dirty air filter	Replace air filter.
ENGINE FALTERS	Choke is opened too soon	Move choke to halfway position until engine runs smoothly.
WATER DRIPPING FROM UNDER PUMP	Piston packing worn	Contact local dealer.
	O-Ring plunger retainer worn	Contact local dealer.
	Cracked piston	Contact local dealer.
OIL DRIPPING	Oil seal worn or damaged	Contact local dealer.
WATER LEAKING FROM PUMP PROTECTOR	Spray gun closed with machine running 5 minutes or longer	Open spray gun or turn off machine.
	Excess water supply pressure	Place a pressure regulator at end of 50' garden hose.
NO DETERGENT	Detergent suction tube not properly connected to machine	Check connection.
	Detergent is too thick	Dilute detergent. For best results, use manufacturers detergent.
	Detergent filter valve is at lowest setting	Set detergent filter valve to a higher setting.
	Filter on detergent suction tube is clogged	Run warm water through filter to remove debris.
	Damaged or clogged detergent suction tube	Remove obstruction or replace detergent suction tube.
	A high pressure nozzle is attached.	Replace with black detergent nozzle.
	Discharge nozzle is obstructed	Blow out or remove debris with fine needle.
GARDEN HOSE CONNECTION LEAKS	Loose fittings	Tighten fittings.
	Missing/worn rubber washer	Insert new washer.
SPRAY WAND LEAKS	Spray wand not properly attached	Slide the spray wand into the gun. Turn the wand collar clockwise onto the spray gun threads until tight.
	Broken o-ring	Call your distributor and order an o-ring.
PUMP IS NOISY	Pump is sucking air	Check that hoses and fittings are air tight. Turn off machine and purge pump by squeezing trigger gun until a steady flow of water emerges through nozzle.

PREVENTATIVE MAINTENANCE

This pressure washer was produced with the best available materials and quality craftsmanship. However, you as the owner have certain responsibilities for the correct care of the equipment. Attention to regular preventative maintenance procedures will assist in preserving the performance of your equipment. Contact your dealer for maintenance. Regular preventative maintenance will add many hours to the life of your pressure washer. Perform maintenance more often under severe conditions.


MAINTENANCE SCHEDULE		
Engine Oil	Inspect	Daily
	Change	First month or 20 hours. Every 100 hours or every 6 months after first month.
	Filter	Every 50 hours.
Air Cleaner/Filter	Inspect	Every 50 hours
	Clean	Monthly
Engine Fuel Filter		500 hours or 6 months
Spark Plug Maintenance		300 hours or annually
Clean Fuel Tank(s)		Annually
Replace Fuel Lines		Annually
Pump Oil	Inspect	Oil level daily
	Change	After first 50 hours, then every 500 hours or annually
Replace High Pressure Nozzle		Every 6 months
Replace Quick Connects/O-Rings		Annually/As needed
Clean Water Screen/Filter		Weekly
Replace HP Hose		Annually (if there are any signs of wear)

OIL CHANGE RECORD

Check pump oil and engine oil level before first use of your new pressure washer.

Date Oil Changed Month/Day/Year	Estimated Operating Hours Since Last Oil Change	Date Oil Changed Month/Day/Year	Estimated Operating Hours Since Last Oil Change

EXPLODED VIEW



EXPLODED VIEW PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY
1		Engine, See Specifications Page	
2		Pump, See Specifications Page	
3		Unloader, See Specifications Page	
4	9.804-025.0	Pump Protector, 1/4" 145° (100, 101)	1
	8.707-256.0	Pump Protector, 1/2" PTP (102, 104, 103)	1
5	9.802-146.0	Swivel, 1/2" MP x 3/4" GHF (100, 101, 102, 104, 103)	1
6	9.802-171.0	Nipple, 3/8" x 3/8" NPT ST Fem (101)	1
	9.802-171.0	Nipple, 3/8" x 3/8" MPT Male (100, 102, 103, 104)	1
7	9.802-142.0	Hose, 1/4" Push-on (E-Z-Start, 9 HP, 11 HP, 13 HP Honda)	14 in
8	8.707-182.0	▲ Coupler, Twist Connect, M22-F x 3/8" FNPT (232336 and 23326)	1
9	9.802-142.0	Hose, Barb, 1/4" Barb x 1/8" MP, 90° (E-Z Start)	1
		(11 HP, 13 HP Honda)	2
	8.706-958.0	Hose Barb, 1/4" Barb x 1/4" Pipe (9 HP)	1
10	9.802-190.0	Valve, E-Z Start 3/8" MPT x 1/8" FPT (9HP, 11HP, 13HP Honda)	1
11	9.803-126.0	Base, CW Direct, Black	1
12	9.802-210.0	Clamp, Hose, (E-Z Start, 9 HP, 11 HP, 13 HP Honda)	4
		(5.5HP, 6HP)	2
13	9.802-711.0	Bolt, 5/16-24" x 1" NF, HH	4
	9.802-722.0	Bolt, 3/8" x 1-1/4" NC, HH (9 HP, 11 HP, 13 HP)	4
	9.802-707.0	Bolt, 5/16"-24 x 3/4"	4
14	9.802-216.0	Injector, Detergent, Assembly All Models Except (110)	1
	9.802-216.0	Injector, Chemical, Non-Adjust	1
	8.707-057.0	Strainer, Plastic, 1/4" Hose Barb	1
	9.802-251.0	Tube, 1/4" x 1/2" Clear Vinyl	6 ft.
15	9.800-723.0	Label, Instructions	1
16	9.802-160.0	Strainer, Plastic, 1/4" Hose Barb	1
17		Hose, High Pressure, See Specifications Page	
18	9.802-223.0	Spray Gun, SK2, 3/8" Inlet, Lance W/M22CPLR	1
	8.711-348.0	Spray Gun, AP 1000	1
19	9.802-220.0	Wand, 18" M22 x 1/4" QC	1
	9.802-219.0	Wand Assy, Side Grip w/1/4" Coupler	1

ITEM	PART NO.	DESCRIPTION	QTY
20		Nozzle Size, See Page 19 For Proper Size	
	4-12803000	Nozzle, 3.0 0° Red	1
	4-12803015	Nozzle, 3.0 15° Yellow	1
	4-12803025	Nozzle, 3.0 25° Green	1
	4-12803040	Nozzle, 3.0 40° White	1
	4-12803500	Nozzle, 3.5 0° Red	1
	4-12803515	Nozzle, 3.5 15° Yellow	1
	4-12803525	Nozzle, 3.5 25° Green	1
	4-12803540	Nozzle, 3.5 40° White	1
	4-12804000	Nozzle, 4.0 0° Red	1
	4-12804015	Nozzle, 4.0 15° Yellow	1
	4-12804025	Nozzle, 4.0 25° Green	1
	4-12804040	Nozzle, 4.0 40° White	1
	4-16540	Nozzle, Compl, QCEM-6540, Brass (All Models)	1
21	9.803-097.0	Axle, 5/8" x 20.125" Long	1
22	9.800-006.0	Label, HOT	1
23	9.802-713.0	Bolt, 5/16" x 1-1/2", NC HH (5 HP, 5.5 HP, 6.5 HP)	4
	9.802-727.0	Bolt, 3/8" x 1-3/4" Tap (9 HP, 11 HP, 13 HP)	4
24	9.802-807.0	Washer, 3/8" SAE, Flat	6
25	9.802-779.0	Nut, 3/8" ESNA, NC	6
26	9.802-728.0	Bolt, 3/8" x 2" NC, HH	4
27	9.803-114.0	Retainer Bracket, Handle, Black	2
28	9.802-773.0	Nut, 1/4" ESNA, NC	6
29	9.802-802.0	Washer, 1/4" Flat	6
30	9.802-064.0	Grommet, Rubber, Nozzle Holder,	5
31	9.802-778.0	Nut, 5/16" Flange, Whiz Loc	2
32	9.803-119.0	Handle, Grab, Chrome	1
33	9.803-126.0	Plate, Warning, Black	1
34	9.803-098.0	Hanger, Hose/Wand	1
35	9.802-706.0	Bolt, 1/4"-20 x 1-3/4", Carriage, Zinc	6
36	9.803-119.0	Handle, Lower Grab, Chrome	1
37	9.802-066.0	Pad, Soft Rubber	2
38	9.802-817.0	Washer, 3/8" x 1" Steel	2
39	9.802-729.0	Bolt, 3/8" x 2-1/4" HH, Grd. 5	2
40	9.802-804.0	Bolt, Carriage, 5/16" x 1-3/4"	4
41	9.802-804.0	Washer, 5/16" Flat	4
42	9.802-776.0	Nut, 5/16" ESNA, NC	4
43	9.803-123.0	Handle, Bumper, Chrome	1
44	9.802-103.0	Bushing, 5/8" Snap	2
45	9.802-270.0	Wheel & Tire Assy, 4" Steel Rim w/Tube	2
46	9.802-782.0	Collar, 5/8" Bore Shaft	2
47	9.800-008.0	Label, Cool Engine Before Filling	1
48	9.802-810.0	Washer, 5/8" Flat	2

EXPLODED VIEW PARTS LIST CONT.

ITEM	PART NO.	DESCRIPTION	QTY
49	9.802-958.0	Key, .185 Sqr x 1.75" (5 HP, 5.5 HP, 6.5 HP)	1
50	9.802-251.0	Tube, 1/4" x 1/2" Clear Vinyl	6 ft.
51	9.800-049.0	Label, Manufacturer's Cleaning Solution	1
52	9.802-776.0	Nut, 5/16" ESNA, NC (5 HP, 5.5 HP, 6.5 HP)	4
	9.802-779.0	Nut, 3/8" ESNA, NC (9 HP, 11HP, 13 HP)	4
53	9.802-804.0	Washer, 5/16" Flat (5 HP, 5.5 HP, 6.5 HP)	8
	9.802-807.0	Washer, 3/8" Flat (9 HP, 11 HP, 13 HP)	12
54	9.802-169.0	Coupler, 3/8" Male Brass	1
55	8.706-854.0	Tee, 1/4" Branch, Male	1
56	9.802-813.0	Lock Washer	4


▲ Not Shown

SPECIFICATIONS

Machine Model	GPM	Pressure (PSI)	Nozzle Size	Hose Part #	Pump Model	Pump Part #	Unloader Part #	Engine Hp	Engine Part #
1.575-100.0	2.3	2400	3.0	8.739-125.0	KG2530G	9.803-822.0	9.803-899.0	GC160 (5.5)	9.802-316.0
1.575-101.0	2.5	2700	3.0	8.739-125.0	KG2530G	9.803-822.0	9.803-899.0	GX200 (6.5)	9.802-317.0
1.575-102.0	3.0	3000	3.5	8.739-125.0	KG3035G1	9.804-034.0	9.803-899.0	GX270 (9)	9.802-315.0
1.575-104.0	3.8	3500	4.0	8.739-203.0	KS4040G	9.802-350.0	9.803-900.0	GX390 (13)	9.802-322.0
1.575-110.0	2.3	2300	3.0	8.739-125.0	2427G	9.120-032.0	9.803-900.0	GC160	9.802-316.0
1.575-103.0	3.8	3200	4.0	8.739-203.0	KS3540G1	9.802-349.0	9.803-900.0	GX390	9.802-316.0

VBA35 UNLOADER EXPLODED VIEW

9.803-899.0 & 9.803-900.0 Unloader, 25 lpm @ 240 BAR, Fits with KG2530 Pump




VBA35 UNLOADER EXPLODED VIEW PARTS LIST

ITEM	PART NO.	DESCRIPTION	KIT	QTY	ITEM	PART NO.	DESCRIPTION	KIT	QTY
1	9.803-902.0	Body Valve (KG)		1	15	9.803-916.0	Spring	B	1
	9.803-901.0	Body Valve (KS)		1	16	9.803-917.0	Poppet	B	1
2	9.803-903.0	O-Ring	A, C	1	17	9.802-893.0	Seal Washer 3/8		2
3	9.803-904.0	Seat	C	1	18	9.803-920.0	Banjo Bolt, 3/8 w/ 1/8 Pilot		1
4	9.803-905.0	Ball, Sub-assy	C	1	19	9.803-915.0	Banjo Bolt 1/2		1
5	9.803-906.0	O-Ring	A	1	20	9.803-921.0	Seal Washer 1/2		2
6	9.803-907.0	Guide Bushing		1	21	9.803-922.0	Plate	C	1
7	9.803-908.0	Teflon Ring	A	1	22	9.803-923.0	Spring	C	1
8	9.803-909.0	O-Ring	A	2	23	9.803-924.0	Set Screw		1
9	9.803-910.0	O-Ring	A	1	24	9.803-925.0	Nut		1
10	9.803-911.0	Connector		1	25	9.803-926.0	Brass Handle		1
11	9.803-912.0	Teflon Ring	A	1	Kit A	9.803-927.0	O-Ring Repair Kit		
12	9.803-913.0	Stem	C	1	Kit B	9.803-928.0	Outlet Kit		
13	9.803-914.0	Connector, Female		1	Kit C	9.803-929.0	Stem Repair Kit		
14	9.803-919.0	O-Ring	A, B	1					

KG PUMP EXPLODED VIEW

9.803-822.0 KG2530G
9.803-823.0 KG3030G



TORQUE SPECS

Item #	Ft.-lbs
14	65
17	18
25	7.6
36	8
38	9
47	13

KG PUMP EXPLODED VIEW PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	9.803-938.0	Crankcase	1	18	9.802-884.0	Washer	8
2*	See Kit Below	Plunger Oil Seal	3	19	9.803-198.0	Copper Washer 3/8"	1
3*	9.803-939.0	O-Ring Ø1.78 x 28.30	3	20	9.802-925.0	Brass Plug 3/8"	2
4*	8.717-310.0	Pressure Ring, 15mm	3	25	9.802-939.0	Hexagonal Screw	9
5*	See Kit Below	"V" Seal, 15mm	6	26	9.803-953.0	Bearing Cover	1
6*	9.803-942.0	Support Ring 15mm	6	27	9.803-954.0	Seal Bearing	1
7*	9.803-944.0	Intermediate Ring 15mm	3	28	9.802-914.0	Snap Ring	1
8	9.802-926.0	Brass Plug, 1/2"	1	29	9.803-955.0	Ball Bearing	1
9	9.803-199.0	Copper Washer 1/2"	1	30	8.717-069.0	Crankshaft (2530G)	1
10	9.803-946.0	Manifold Housing	1		8.717-070.0	Crankshaft (3030G)	1
11*	9.803-947.0	O-Ring Ø1.78 x 15.54	6	31	9.803-957.0	Oil Dip Stick	1
12*	See Kit Below	Valve Assembly	6	32	9.804-581.0	O-Ring 3.53 x 55.56	1
13*	9.803-948.0	O-Ring Ø2.62 x 18.77	6	33	9.804-582.0	Needle Roller Bearing	1
14	9.803-949.0	Valve Plug	6	34	8.717-212.0	Engine Flange	1
15	9.803-950.0	Washer, Copper	1	35	9.803-210.0	Spring Washer	4
16	9.803-951.0	Brass Plug G1/4	1	36	9.804-584.0	Flange Screw	4
17	9.803-952.0	Manifold Stud Bolt	8				

KG PUMP EXPLODED VIEW


ITEM	PART NO.	DESCRIPTION	QTY
37	9.804-586.0	Crankshaft Seal	1
38*	9.803-959.0	Plunger Nut	3
39*	See Kit Below	Plunger, 15mm	3
40*	9.803-962.0	Copper Spacer	3
41*	9.803-963.0	O-Ring Ø1.78x5.28	3
42*	9.803-156.0	Teflon Ring	3
43	9.803-964.0	Plunger Rod	3
44	9.803-965.0	Connecting Rod Pin	3
45	9.803-966.0	Connecting Rod	3
46	9.803-218.0	Spring Washer	6
47	8.933-020.0	Connecting Rod Screw	6
48	9.803-969.0	O-Ring 2.62 x 107.62	1
49	9.803-968.0	Crankcase Cover	1
50	9.803-197.0	Gasket, G3/8	1
51	9.803-202.0	Sightglass G3/8	1

* Part available in kit (See below)

REPAIR KIT NUMBER	9.803-930.0	9.803-932.0	9.803-934.0	9.803-936.0	9.803-937.0
KIT DESCRIPTION	Plunger Seal 15mm	Complete Seal Packing 15mm	Plunger 15mm	Complete Valve	Plunger Oil Seals
ITEM NUMBERS INCLUDED	3, 5, 6	2, 3, 4, 5, 6, 7	38, 39, 40, 41, 42	11, 12, 13	2
NUMBER OF CYLINDERS KIT WILL SERVICE	3	1	1	6	3

KS-1 PUMP EXPLODED VIEW

9.841-643.0 KS3040G-1
 9.802-349.0 KS3540G-1
 9.802-350.0 KS4040G-1
 9.803-409.0 KS5030G-1



KS-1 PUMP EXPLODED VIEW PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	8.717-129.0	Crankcase	1	18	9.803-198.0	Copper Washer 3/8"	1
2	9.803-196.0	Plunger Guide	3	19	9.802-925.0	Brass Plug 3/8"	2
3*	See Kit Below	Plunger Oil Seal	3	24	9.802-939.0	Hexagonal Screw	9
4*	9.803-189.0	O-Ring Ø1.78 x 31.47	3	25	9.803-210.0	Washer	4
5*	See Kit Below	"V" Seal , 15mm	6	26	9.803-184.0	Closed Bearing Housing	1
6*	8.717-310.0	Pressure Ring, 15mm	3	27	8.717-225.0	O-Ring Ø 1.78 x 60.05	2
7*	8.717-179.0	Support Ring 15mm	6	28	9.802-914.0	Snap Ring	1
8*	8.717-178.0	Intermed. Ring 15mm	3	29	9.803-168.0	Double Row Ball Bearing	1
9	9.802-926.0	Brass Plug, 1/2"	1	30	9.803-150.0	Crankshaft (KS3040G-1)	1
10	9.803-199.0	Copper Washer 1/2"	1		9.803-151.0	Crankshaft (KS3540G-1)	1
11	9.802-932.0	Manifold Housing	1		9.803-152.0	Crankshaft (KS4040G-1)	1
12*	9.803-191.0	O-Ring Ø2.62 x 17.13	6		9.803-153.0	Crankshaft (KS5030G-1)	1
13*	See Kit Below	Valve Assembly	6	31	9.802-945.0	Set Screw	1
14*	9.803-193.0	O-Ring Ø2.62 x 20.29	6	32	9.802-921.0	Oil Dip Stick	1
15	9.802-928.0	Valve Plug	6	33	9.804-581.0	O-Ring Ø 3.53 x 55.56	1
16	9.802-938.0	Manifold Stud Bolt	8	34	9.803-161.0	Needle Roller Bearing	1
17	9.802-884.0	Washer	8	35	9.803-183.0	Engine Flange	1

KS-1 PUMP EXPLODED VIEW PARTS LIST (CONT.)

ITEM	PART NO.	DESCRIPTION	QTY
36	9.803-221.0	Spring Washer	4
37	9.803-240.0	Flange Screw	4
38	9.803-243.0	Engine Screw, 5/16"	4
39	9.803-215.0	Washer	4
40	9.802-889.0	Spring Washer	4
41	9.803-244.0	Engine Screw 3/8"	4
42	9.803-216.0	Washer	4
43	9.803-217.0	Spring Washer	4
44	9.803-142.0	Crankshaft Seal	1
45*	9.803-959.0	Plunger Nut	3
46*	See Kit Below	Plunger, 15mm	3
47*	9.803-962.0	Copper Spacer	3
48*	9.803-963.0	O-Ring Ø1.78x5.28	3
49*	9.803-156.0	Teflon Ring	3
50	9.803-145.0	Plunger Rod	3
51	9.802-913.0	Snap Ring	6
52	9.802-916.0	Connecting Rod Pin	3
53	9.803-158.0	Connecting Rod	3
54	9.803-218.0	Spring Washer	6
55	9.803-238.0	Connecting Rod Screw	6
56	8.933-016.0	Cover Gasket	1
57	8.717-145.0	Crankcase Cover	1
58	9.803-906.0	O-Ring, Ø 1.78 x 14	1
59	9.803-202.0	Sight Glass, G3/4	1

* Part available in kit (See below)

REPAIR KIT NUMBER	9.802-622.0	9.802-623.0	8.933-023.0	9.802-603.0	9.802-609.0
KIT DESCRIPTION	Plunger Seal 15mm	Complete Seal Packing 15mm	Plunger 15mm	Complete Valve	Plunger Oil Seals
ITEM NUMBERS INCLUDED	4, 5, 7	4, 5, 6, 7, 8	45, 46, 47, 48, 49	12, 13, 14	3
NUMBER OF CYLINDERS KIT WILL SERVICE	3	1	1	6	3

**LIMITED NEW PRODUCT
WARRANTY—COMMERCIAL
PRESSURE WASHERS**



www.karchercommercial.us

WHAT THIS WARRANTY COVERS

All Kärcher commercial pressure washers are warranted by Kärcher to the original purchaser to be free from defects in materials and workmanship under normal use, for the periods specified below. This Limited Warranty, subject to the exclusions shown below, is calculated from the date of the original purchase, and applies to the original components only. Any parts replaced under this warranty will assume the remainder of the pressure washer's warranty period.

FIVE YEAR PARTS AND ONE YEAR LABOR WARRANTY

Components manufactured by Kärcher, such as frames, handles, float tanks, fuel tanks, belt guards, and heating coils. Internal components on the oil-end of Kärcher axial pumps have a 5 year warranty. Period of warranty on axial pumps shall be one year. Kärcher crankshaft pumps have a 7 year warranty on non-wear parts. Heating coils are pro-rated at 25% after 2 years. Stainless steel coils have a 10 year warranty.

ONE YEAR PARTS AND ONE YEAR LABOR WARRANTY

All other components, excluding normal wear items as described below, will be warranted for one year on parts and labor. Parts and labor warranty on these parts will be for one year regardless of the duration of the original component manufacturer's part warranty.

WARRANTY PROVIDED BY OTHER MANUFACTURERS

Motors, generators, and engines, which are warranted by their respective manufacturers, are serviced through these manufacturers' local authorized service centers. Kärcher is not authorized and has no responsibility to provide warranty service for such components. Motors manufactured outside of the United States will be warranted by Kärcher.

WHAT THIS WARRANTY DOES NOT COVER

This warranty does not cover the following items:

1. Normal wear items, such as nozzles, spray guns, discharge hoses, wands, quick couplers, seals, filters, gaskets, O-rings, packings, pistons, pump valve assemblies, strainers, belts, brushes, rupture disks, fuses, pump protectors.
2. Any components or other devices incorporated into a Kärcher product that are not manufactured by Kärcher, including, but not limited to gasoline engines, pumps, etc.
3. Defects caused by improper or negligent operation or installation, accident, abuse, misuse, neglect, unauthorized modifications, repair or maintenance of the product by persons other than authorized representatives of Kärcher, including, but not limited to, the failure of the Customer to comply with recommended product maintenance schedules.
4. Kärcher products that have been returned by the original Customer and are ultimately re-sold by an Authorized Servicing Dealer or other sales or service outlet to another purchaser.
5. Kärcher products that are sold by any distributor or retailer that is not an official authorized dealer or retailer of Kärcher products.
6. Defects caused by acts of nature and disaster including, but not limited to, floods, fires, wind, freezing, earthquakes, tornadoes, hurricanes and lightning strikes.
7. Defects caused by water sediments, rust corrosion, thermal expansion, scale deposits or a contaminated water supply (such as water in the unit with chloride content higher than that of 80 mg/liter or use of chemicals not approved or recommended by Kärcher).
8. Defects caused by improper voltage, voltage spikes or power transients in the electrical supply.
9. Devices or accessories not distributed or approved by Kärcher.
10. Any cost of labor arising from the removal and reinstallation of the alleged defective part by Customer.
11. Transportation of the product to an Authorized Servicing Dealer, field labor, replacement rental and any freight charges.

Any components, accessories or other devices provided with the product but not manufactured by Kärcher (such as engines, pumps, etc.) are subject to warranties and service through their respective manufacturers authorized service centers and according to the applicable terms and conditions of such manufacturers warranties. Such components or other devices not manufactured by Kärcher should be referred by the Customer to an authorized service center or their respective manufacturers for repair or replacement.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, WHETHER ARISING BY LAW, CUSTOM OR CONDUCT. KÄRCHER MAKES NO ADDITIONAL WARRANTIES, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY EXPRESSED OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS OF EQUIPMENT FOR A PARTICULAR PURPOSE AND ANY SUCH WARRANTIES ARE EXPRESSLY DISCLAIMED. KÄRCHER FURTHER DISCLAIMS ANY WARRANTY THAT THE PRODUCT PURCHASED BY CUSTOMER WILL MEET ANY PARTICULAR REQUIREMENT OF CUSTOMER EVEN IF KÄRCHER HAS BEEN ADVISED OF SUCH REQUIREMENT.

THE RIGHTS AND REMEDIES PROVIDED UNDER THIS WARRANTY ARE EXCLUSIVE AND IN LIEU OF ANY OTHER RIGHTS OR REMEDIES OF CUSTOMER. KÄRCHER SHALL NOT UNDER ANY CIRCUMSTANCES BE LIABLE TO ANY PERSON OR ENTITY INCLUDING, BUT NOT LIMITED TO, THE CUSTOMER OR ANY END USER OF THE PRODUCT FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR ECONOMIC LOSS, LOSS OF PROFITS OR LOSS OF USE OF THE PRODUCT, ARISING IN CONNECTION WITH THE SALE, DELIVERY, INSTALLATION, TRAINING OR USE OF PRODUCT. KÄRCHER'S LIABILITY, WHETHER IN CONTRACT OR IN TORT, ARISING OUT OF ANY WARRANTIES OR REPRESENTATIONS, INSTRUCTIONS OR DEFECTS FROM ANY CAUSE, SHALL BE LIMITED EXCLUSIVELY TO THE COST OF REPAIR OR REPLACEMENT PARTS UNDER AFORESAID CONDITIONS.

The purpose of the foregoing limitations on liability and Customer remedies is to protect Kärcher from unknown or undeterminable risks. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to the Customer.

Kärcher sales and service representatives are not authorized to waive or alter the terms of this warranty, or to increase the obligations of Kärcher under the warranty.

Kärcher reserves the right to make design changes in any of its products without prior notification to the Customer.



Form #9.800-082.0 • Revised 01/08 • Printed in U.S.A.